



INSTALLATION INSTRUCTIONS

PART No.

FB21353

**Ford 2015-2017 F-150/17-21 Raptor
Hood Light Pod Brackets**



REQUIRED TOOLS

10mm Socket

KIT CONTAINS

Light Pod Bracket (Driver/Passenger)

QTY

1ea

2135300

1) REMOVE & INSTALL

Just underneath the windshield plastic cowl on both the driver and passenger sides is a bolt. With a 10mm socket, remove this bolt.



Place the side specific bracket over the bolt hole, and secure the bracket the factory bolt.



Install your pod light.

