



INSTALLATION INSTRUCTIONS

PART No.

FB22367

**07-13 Chevy/GMC 1500
Rear Bumper**



VIDEO AVAILABLE



REQUIRED TOOLS

17mm Socket
21mm Wrench
22mm Socket

Help of a friend

KIT CONTAINS

Chevy Rear Bumper
D-Ring
Bumper Rail Brackets
M14 Hex Bolt
M14 Nyloc Nut
M14 Washer
M10 Hex Bolt
M10 Nyloc Nut
M10 Washer
M6 Counter Sunk Screw
M6 Nyloc Nut
M6 Washer
M6 Button Head Bolt

QTY

1
2
2
8
8
16
2
2
4
2
2
2
6

2236700

1) REMOVE EXISTING BUMPER

Begin removing your vehicle's existing front bumper, fog lights, sensors, and grille. We show how to remove and disassemble your factory bumper over at

www.YouTube.com/FishboneOffroad



3) INSTALL

With the help of a friend, lift the bumper up to the bumper brackets and loosely secure it with the remaining M14 bolts. Adjust and center the bumper as desired, and completely tighten the bumper down.

2) ASSEMBLE

With a 21mm wrench, 22mm socket, and 17mm socket, install the bumper brackets onto the frame rail with 4 out of the 8 M14 bolts and nuts, as well as an M10 bolt, 2 washers, and nut on each side.





INSTALLATION INSTRUCTIONS

PART No.

FB22367

**07-13 Chevy/GMC 1500
Rear Bumper**

Install your factory license plate lights into the bumper with the included plastic push clips. Install your trailer connector using the included M6 bolts and nuts, followed by securing the wiring harness as desired. You will need to purchase newer style lights to accommodate our brackets.

