



INSTALLATION INSTRUCTIONS

PART No.

FB22368

**07-13 Chevy/GMC 1500
Front Bumper**



VIDEO AVAILABLE



REQUIRED TOOLS

18mm Wrench
18mm Socket
19mm Wrench

Help of a friend

KIT CONTAINS

Chevy Front Bumper
D-Ring
M12 Hex Bolt
M12 Nyloc Nut
M12 Washer

QTY

1
2
8
8
8

2236800

1) REMOVE EXISTING BUMPER

Begin removing your vehicle's existing front bumper, fog lights, sensors, and grille. We show how to remove and disassemble your factory bumper over at

www.YouTube.com/FishboneOffroad



2) ASSEMBLE

Begin loosely installing the winch plate by reusing the factory hardware. Install your winch and light bar according to the manufacturer's instructions at this time.



3) INSTALL

With the help of a friend, lift the bumper up to the winch plate and frame and loosely secure it with the included hardware, with an 18mm and 19mm socket. Adjust and center the bumper as desired, and completely tighten the bumper down.





INSTALLATION INSTRUCTIONS

PART No.

FB22368

**07-13 Chevy/GMC 1500
Front Bumper**

