



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB25231**

**Jeep® '18-Current JL Wrangler  
Tub Rail Tie Downs**



## REQUIRED TOOLS

## KIT CONTAINS

## QTY

JL Tub Rail Tie Down (Left & Right)  
Hardtop Knobs  
5/16" Flat Washer

1 ea  
4  
4

### 1) REMOVE TUB ACCESSORIES

Prepare the installation area by removing any accessories from your tub rails, including our storage racks, bins, and any hardtop Torx bolts.



Depending on your preference or setup, the Tie Down will sit on top of any accessory, meaning the included knobs will secure it and anything extra.



### 2) TIE DOWN ORIENTATION

Determine the orientation you'd like for the Tie Downs, as they're driver and passenger side specific, but can be swapped by rotating them to face inboard or outboard.



### 3) INSTALL

Place all your desired accessories onto the rail with the Tie Down finally on top. With 2 of the included knobs and washers, secure the Tie to the tub rail.





Repeat on the opposite side.

- 4) ENJOY YOUR NEW FISHBONE OFFROAD TUB RAIL  
TIE DOWNS!**

